

PHC40 Ordering Instructions

Required Configurations								
PHC40	-	2	-	B01	-	E3	-	OR1
		①		②		③		④

Bold	= standard option
-------------	-------------------

Please select one option from each of the required fields (1 - 6). To configure your pump with different port fittings, optionally use sections 3-5 as needed. To configure sensor options or leak detection, please select options from the appropriate additional options (7-13).

① ② Number of Chambers and Air Fitting Configuration	
① Ports	④ Fitting Style
2 = Two Chamber	B01 = M6 Flat Bottom
	B02 = 1/4 - 28 Flat bottom
③ Electrical Connection	
E1	= 15' PVC Jacketed Cable
E3	= Turck Connector
E4	= Turck Connector with mating 6 meter pigtail
④ Oring Material	
OR1	=FKM
OR2	=FFKM

The following configuration has 2 Chambers, M6 flat bottom liquidn connections and turck connectors and FKM Orings;

PHC40-2-B01-E3-OR1