

# **PXU140 Ordering Instructions**

## Configuration

Required Options (Default Model)

Additional Options (Blank if not needed)

PXU140 -F16

· LF0 - SX1 - TF16 -

Pump Model Check Inlet
Balls Fitting

Leak Stroke Detect Detect Outlet Fitting Revision



#### Instructions

Select all Required Options.
Only add Additional Options if desired.
Only add Outlet Fitting if different than Inlet Fitting.
Contact support for revision or copy exact information.

### - Required Options -

#### Default options are highlighted

Standard Model F	PXU140

Check Balls	
PTFE Check balls	blank
PFA Check balls	F

Inlet Fitting Front straight only	/		
Flaretek	1/2 in.	F08	
Compatible	3/4 in.	F12	
Con	1 in.	F16	
	1-1/4 in.	F20	
Tube Out	3/4 in.	T12	
	1 in.	T16	
	1-1/4 in.	T20	
	1-1/2 in.	T24	
Weldable	3/4 in.	W12	
	1 in.	W16	
Pillar S-300	1/2 in.	P08	
Tillar 3 300	3/4 in.	P12	
	1 in.	P16	
	1-1/4 in.	P20	
	1-1/2 in.	P24	
FNPT	3/4 in.	N12	
	1 in.	N16	
	1-1/4 in.	N20	
Synchro-Flare	1/2 in.	S08	
O.	3/4 in.	S12	
Synchroniale	1 in.	S16	
Primel ock	3/4 in.	L12	
TO O O	1 in.	L16	
-00	1-1/4 in.	L20	

# Additional Options

No leak detection blank  15 ft fiber optic cable with no amplifier LF0  15 ft fiber optic cable with D10 amplifier LF1		
15 ft fiber optic cable with D10 amplifier LE1		
25 ft fiber optic cable with no amplifier LF2		
25 ft fiber optic cable with D10 amplifier LF3		
15 ft conductivity cable LC0		
25 ft conductivity cable LC1		

Stroke Detection	
No stroke detection	blank
15 ft PNP normally open proximity switch	SX1

\* Proximity switch ordered separately. Proximity switch is required for operation. Standard configuration does NOT include proximity switch.

For applications requiring the NPN signal, White Knight recommends the use of a signal converter similar to Balluf part number BAE002H.



Timer mode operation requires end-of-stroke detection. Use of timer mode without stroke detection voids the warranty.

This pump includes Quick Exhaust Valves (QEVs). QEVs must be used with this pump. Running it without QEVs voids its warranty. Customers may use their own QEVs with the optional NPT adapter.

Outlet Fitting Straight only. Select Top or Fron	t.	Front	Тор
Same as Inlet Fitt	ing	blank	n/a
Flaretek	1/2 in.	FF08	TF08
Compatible	3/4 in.	FF12	TF12
	1 in.	FF16	TF16
	1-1/4 in.	FF20	TF20
Tube Out	3/4 in.	FT12	TT12
	1 in.	FT16	TT16
	1-1/4 in.	FT20	TT20
	1-1/2 in.	FT24	TT24
Weldable	3/4 in.	FW12	TW12
	1 in.	FW16	TW16
Pillar S-300	1/2 in.	FP08	TP08
Fillal 3-300	3/4 in.	FP12	TP12
	1 in.	FP16	TP16
	1-1/4 in.	FP20	TP20
	1-1/2 in.	FP24	TP24
FNPT	3/4 in.	FN12	TN12
0	1 in.	FN16	TN16
	1-1/4 in.	FN20	TN20
Synchro-Flare	1/2 in.	FS08	TS08
Oynemo Flare	3/4 in.	FS12	TS12
40	1 in.	FS16	TS16
PrimeLock	3/4 in.	FL12	TL12
<b>C</b>	1 in.	FL16	TL16
GOO O	1-1/4 in.	FL20	TL20

Leave blank if Front and same as Inlet Fitting. Select option if Top or different than Inlet Fitting.

K	e	۷I	SI	0	n	

No revision

blank

ī

Contact White Knight support for revision level or copy exact code activation details. Configured part numbers are not Copy Exact Part Numbers. Email: support@wkfluidhandling.com Phone: 435.783.6040

