Configuration



Standard options are highlighted

0. Model		
Standard	D\/	
pressure vessel	FV	

1. Diameter	
4 inch	4

2. Volume	
1 liter	1
2 liter	2
3 liter	3
4 liter *	4
5 liter *	5
6 liter *	6

^{*} Two coupled tubes.

Large Fittings		Top Cap		Bottom Cap	
Large Fi	ttings	3. Port 1	4. Port 2	7. Port 1	8. Port 2
Plugged		B00	B00	B00	B00
Flaretek	1/2 in.	F08	F08	F08	F08
Compatible	3/4 in.	F12	F12	F12	F12
	1 in.	F16	F16	F16	F16
0	1-1/4 in.	F20	F20	F20	F20
Pillar S-300	1/2 in.	P08	P08	P08	P08
Con .	3/4 in.	P12	P12	P12	P12
6	1 in.	P16	P16	P16	P16
FNPT	1/2 in.	N08	N08	N08	N08
0	3/4 in.	N12	N12	N12	N12
	1 in.	N16	N16	N16	N16
Weldable	1/2 in.	W08	W08	W08	W08
	3/4 in.	W12	W12	W12	W12
	1 in.	W16	W16	W16	W16

Small Fittings		Top Cap		Bottom Cap	
		5. Port 3	6. Port 4	9. Port 3	10. Port 4
Plugged		В0	В0	В0	В0
Flaretek	1/4 in.	F4	F4	F4	F4
Compatible	3/8 in.	F6	F6	F6	F6
Pillar S-300	1/8 in.	P2	P2	P2	P2
	1/4 in.	P4	P4	P4	P4
	3/8 in.	P6	P6	P6	P6
FNPT	1/4 in.	N4	N4	N4	N4
	3/8 in.	N6	N6	N6	N6

11. Sensor Brackets			
Two Brackets, No Sensors	В0		
Two Brackets, One Sensor	B1		
Two Brackets, Two Sensors	B2		
Two Brackets, Three Sensors	В3		
Two Brackets, Four Sensors	B4		
Three Brackets, No Sensors	C0		
Three Brackets, One Sensor	C1		
Three Brackets, Two Sensors	C2		
Three Brackets, Three Sensors	СЗ		
Three Brackets, Four Sensors	C4		
Four Brackets, No Sensors	D0		
Four Brackets, One Sensor	D1		
Four Brackets, Two Sensors	D2		
Four Brackets, Three Sensors	D3		
Four Brackets, Four Sensors	D4		

12. Dip Tube * Must match Volume option	
No dip tube	0
Dip tube for 1-liter vessel	1
Dip tube for 2-liter vessel	2
Dip tube for 3-liter vessel	3
Dip tube for 4-liter vessel	4
Dip tube for 5-liter vessel	5
Dip tube for 6-liter vessel	6

Revision	
No revision	blank
Contact White Knight support for relevel or copy exact code activation Configured part numbers are not C Exact Part Numbers. Email: support@wkfluidhandling.co. Phone: 435,783,6040	details. opy

