

PFU060 Ordering Instructions

Configuration

Required Options (Default Model)

Additional Options (Blank if not needed)

PFU060 F-F12

LF0 - SFD0 - TF12

Model

Fitting Balls

Detect Detect

Outlet Fitting Revision



Instructions

Select all Required Options. Only add Additional Options if desired. Only add Outlet Fitting if different than Inlet Fitting. Contact support for revision or copy exact information.

Default options are highlighted

Model	
Standard Model	PFU060
Dry-Run Capable	PFUSD060

2. Check Ball Material		
PFA Check balls	F	
PTFE Check balls	М	

Inlet Fitting Front straight onl	ly	
Flaretek	1/2 in.	F08
Compatible	3/4 in.	F12
Companie	1 in.	F16
	1-1/4 in.	F20
Tube Out	1/2 in.	T08
	3/4 in.	T12
	1 in.	T16
	1-1/4 in.	T20
Weldable	3/4 in.	W12
	1 in.	W16
Pillar S-300	3/8 in.	P06
1 000	1/2 in.	P08
	3/4 in.	P12
	1 in.	P16
	1-1/4 in.	P20
FNPT	1/2 in.	N08
	3/4 in.	N12
	1 in.	N16
Synchro-Flare	1/2 in.	S08
O O O	3/4 in.	S12
0	1 in.	S16
Drimol ook	1/2 in.	L08
Con	3/4 in.	L12
TO O O	1 in.	L16
_	1-1/4 in.	L20

- Required Options - - - - Additional Options

Leak Detection			
blank			
LF0			
LF1			
LF2			
LF3			
LC0			
LC1			

Stroke Detection			
No stroke detection	blank		
DUAL PROBE OPTIONS			
15 ft fiber optic cable with no amplifier	SFD0		
15 ft fiber optic cable with D10 amplifier	SFD1		
25 ft fiber optic cable with no amplifier	SFD2		
25 ft fiber optic cable with D10 amplifier	SFD3		
SINGLE PROBE, DUAL DETECT OPTIONS			
Single probe, dual detect, no fibers	SFS		
15 ft fiber optic cable with no amplifier	SFS0		
15 ft fiber optic cable with D10 amplifier	SFS1		
25 ft fiber optic cable with no amplifier	SFS2		
25 ft fiber optic cable with D10 amplifier	SFS3		

^{*} Fiber optic cables ordered separately. Fiber optics are required for operation. Standard configuration includes dual probe WITHOUT fibers. See stroke detect options to order fiber optic cables or single probe option.



Timer mode operation requires end-of-stroke detection. Use of timer mode without stroke detection voids the warranty.

This pump includes Quick Exhaust Valves (QEV). QEVs must be used with this pump. Operating it without QEVs voids its warranty. Customers may use their own QEVs with the optional NPT adapter.

Outlet Fitting Straight only. Select Top or Front.		Front	Тор
Same as Inlet Fitting		blank	n/a
Flaretek Compatible	1/2 in.	FF08	TF08
	3/4 in.	FF12	TF12
	1 in.	FF16	TF16
	1-1/4 in.	FF20	TF20
Tube Out	1/2 in.	FT08	TT08
	3/4 in.	FT12	TT12
	1 in.	FT16	TT16
	1-1/4 in.	FT20	TT20
Weldable	3/4 in.	FW12	TW12
	1 in.	FW16	TW16
Pillar S-300	3/8 in.	FP06	TP06
Pilial S-500	1/2 in.	FP08	TP08
	3/4 in.	FP12	TP12
	1 in.	FP16	TP16
	1-1/4 in.	FP20	TP20
FNPT	1/2 in.	FN08	TN08
	3/4 in.	FN12	TN12
	1 in.	FN16	TN16
Synchro-Flare	1/2 in.	FS08	TS08
	3/4 in.	FS12	TS12
	1 in.	FS16	TS16
Primal ook	1/2 in.	FL08	TL08
TimeLock To a control of the control	3/4 in.	FL12	TL12
	1 in.	FL16	TL16
	1-1/4 in.	FL20	TL20

Leave blank if Front and same as Inlet Fitting. Select option if Top or different than Inlet Fitting.

Revision

No revision

I

Contact White Knight support for revision level or copy exact code activation details. Configured part numbers are not Copy Exact Part Numbers. Email: support@wkfluidhandling.com Phone: 435.783.6040

